


COUNTER SCREEN


2216



- Allows counters or dials to be viewed from outside enclosure.

COUNTER SCREEN

2215



- Allows counters or dials to be viewed from outside enclosure.